


FULL HEIGHT TURNSTILE

At the end of each step, verify how it is working.

Step 1) Unscrew the mechanism releasing it a little. Do not take it off.

Step 2) Take the mechanism off and verify if there are any marks (scratches) on the central axle or in the protection cover.




If there are any marks:

- Verify superior central part's alignment with the superficie (pallet)





Dimension from
base to the top

- Verify if central part screw holes are in centralized with the holes in the pallet. Same with the structures.



In case there are NO marks:

- Verify if the inferior bearing is not touching in the protection cover (in case it is in contact, the painting will be scratched)



- Verify if the inferior rolling is not "locking" the turn or making it be too heavy.