




Wireless Router

Quick Start Guide

About this Document

- This Document includes instructions for using and managing the Product. Pictures, charts, images and all other information hereinafter are for description and explanation only.
- The information contained in the Document is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version of the Document at the Hikvision website (<https://www.hikvision.com>). Unless otherwise agreed, Hangzhou Hikvision Digital Technology Co., Ltd. or its affiliates (hereinafter referred to as "Hikvision") makes no warranties, express or implied.
- Please use the Document with the guidance and assistance of professionals trained in supporting the Product.

About this Product

This product can only enjoy the after-sales service support in the country or region where the purchase is made.


Acknowledgment of Intellectual Property Rights

- Hikvision owns the copyrights and/or patents related to the technology embodied in the Products described in this Document, which may include licenses obtained from third parties.
- Any part of the Document, including text, pictures, graphics, etc., belongs to Hikvision. No part of this Document may be excerpted, copied, translated, or modified in whole or in part by any means without written permission.
- HIKVISION** and other Hikvision's trademarks and logos are the properties of Hikvision in various jurisdictions.
- Other trademarks and logos mentioned are the properties of their respective owners.

LEGAL DISCLAIMER


- TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THIS DOCUMENT AND THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, ARE PROVIDED "AS IS" AND "WITH ALL FAULTS AND ERRORS". HIKVISION MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, OR FITNESS FOR A PARTICULAR PURPOSE. THE USE OF THE PRODUCT BY YOU IS AT YOUR OWN RISK. IN NO EVENT WILL HIKVISION BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA, CORRUPTION OF SYSTEMS, OR LOSS OF DOCUMENTATION, WHETHER BASED ON BREACH OF CONTRACT, TORT (INCLUDING NEGLIGENCE), PRODUCT LIABILITY, OR OTHERWISE, IN CONNECTION WITH THE USE OF THE PRODUCT, EVEN IF HIKVISION HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR LOSS.
 - YOU ACKNOWLEDGE THAT THE NATURE OF THE INTERNET PROVIDES FOR INHERENT SECURITY RISKS, AND HIKVISION SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER-ATTACK, HACKER ATTACK, VIRUS INFECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, HIKVISION WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED.
 - YOU AGREE TO USE THIS PRODUCT IN COMPLIANCE WITH ALL APPLICABLE LAWS, AND YOU ARE SOLELY RESPONSIBLE FOR ENSURING THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. ESPECIALLY, YOU ARE RESPONSIBLE, FOR USING THIS PRODUCT IN A MANNER THAT DOES NOT INFRINGE ON THE RIGHTS OF THIRD PARTIES, INCLUDING WITHOUT LIMITATION, RIGHTS OF PUBLICITY, INTELLECTUAL PROPERTY RIGHTS, OR DATA PROTECTION AND OTHER PRIVACY RIGHTS. YOU SHALL NOT USE THIS PRODUCT FOR ANY PROHIBITED END-USES, INCLUDING THE DEVELOPMENT OR PRODUCTION OF WEAPONS OF MASS DESTRUCTION, THE DEVELOPMENT OR PRODUCTION OF CHEMICAL OR BIOLOGICAL WEAPONS, ANY ACTIVITIES IN THE CONTEXT RELATED TO ANY NUCLEAR EXPLOSIVE OR UNSAFE NUCLEAR FUEL-CYCLE, OR IN SUPPORT OF HUMAN RIGHTS ABUSES.
 - IN THE EVENT OF ANY CONFLICTS BETWEEN THIS DOCUMENT AND THE APPLICABLE LAW, THE LATTER PREVAILS.
- © Hangzhou Hikvision Digital Technology Co., Ltd. All rights reserved.

Check Packing List



Place the Router

- The closer, the faster.
- Higher and no coverage.
- Place it on the centre to cover more space.




Safety Information

- The socket-outlet shall be installed near the device and shall be easily accessible.
- Install the device according to the instructions in Quick Start Guide.
- To prevent injury, this device must be securely attached to the installation surface in accordance with the installation instructions.
- NEVER place the device in an unstable location to prevent serious personal injury or death caused by device falling.
- If the device is powered by terminals connected to the power cord, ensure correct voltage and wiring of the terminals for connection to mains supply.
- If a power adapter is provided in the device package, use the provided adapter only. If no power adapter is provided, ensure the power adapter or other power supply complies with Limited Power Source. Refer to the product label for the power supply output parameters.
- If the device needs to be wired by yourself, select the corresponding wire to supply power according to the electric parameters labeled on the device. Strip off wire with a standard wire stripper at corresponding position. To avoid serious consequences, the length of stripped wire shall be appropriate, and conductors shall not be exposed.
- Make sure that the power has been disconnected before you wire, install, or disassemble the device.
- If smoke, odor, or noise arises from the device, immediately turn off the power, unplug the power cable, and contact the service center.

1 Learn About Router

Introduction of status indicator and interfaces.



Status Indicator


- Solid Blue:** Network is connected.
- Flashing Blue:** WPS is pairing or restored to default.
- Solid Red:** Not activated or connection exception.
- Flashing Red:** WPS is pairing.

WPS

- Long press 1-3s to access wireless WPS devices.
- Long press 5s to relay to other routers.

Power

Connect to the power cord.



Reset

Long press 8s to restore to defaults.

Adaptive Network Interface

Connect to modem, other routers, or PC.


2 Connect Power Supply and Internet

Refer to the figures below to complete the Internet and power connection of the router.

Connect to the Internet




Optical Fiber




Ethernet Cable

Connect to Power Supply



Indicator is Solid RED



Go to the next step: **Activate Router**

3


Activate Router

Follow these steps to complete the initial activation of the router.

Check the Label


Obtain Wi-Fi name and IP address.

Wi-Fi Name(SSID): HIKVISION_XXXX
IP Address: 192.168.9.1




Connect to a Wi-Fi Network

Connect your device to the Wi-Fi.



Enter Activation Page

Automatically redirect to the page.




If not, you can manually enter IP address (**192.168.9.1**) in the browser.

Start Initial Configuration


Follow the steps below to complete the configuration.

1. Device Connection



Make sure the router is connected to the network.


2. Network Config: Detect your network type or select manually.



- **DHCP** is recommended. No configure is required.
- Select **PPPoE** if your ISP has provided broadband account and password.
- **Static IP** is not recommended unless your ISP has provided an IP address and other information.

NOTE: Make sure the Ethernet cable is connected to Port 1 if you enabled VLAN. Please check more information on User Manual.


3. Route Settings




- Set Wi-Fi password
- Select your Country/Region
- Set Admin password

Completed

Wi-Fi will restart.



Indicator is Solid BLUE



Reconnect to the Wi-Fi after status checking.

Enjoy fast and smooth surfing !



Manage Your Router Anytime, Anywhere

1. Download Apps

Scan the QR code below to download the apps. Both the apps can help you manage your device remotely.



HIK-Connect
(For End User)



HIK-Partner Pro
(For Partner)

2. Open an App and Login

Create a new account to login if you don't have one before.

3. Add Device

Scan the QR code on the lable of the router, and follow the steps on the APP to complete the setup.



See Far, Go Further